



AIRPORT DIAGRAM

TCN:	ATIS:	GND:	TWR:	APP/DEP:	TA(ft) / TL:	ARP GPS:	ELEV:
045X	127.45	360.75	341.40	292.425	11,000/FL110	N 32°38.607' E 35°13.721'	193 FT



Departure: Apron A will be used for departure on RWY 15.
Apron G will be used for departure on RWY 33.
Apron C will be used for departure on RWY 09.
Apron F will be used for departure on RWY 27.

Warning:
RWY 11-29 may be closed or not supported in BMS.



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAYS HOLDING INSTRUCTIONS IS REQUIRED.

Rwy	Length	TODA	LDA
15	8209' / 2503m	8080' / 2503m	7796' / 2377m
33	8209' / 2503m	7956' / 2426m	8209' / 2503m
09	8690' / 2649m	8561' / 2610m	8690' / 2649m
27	8690' / 2649m	8392' / 2559m	8653' / 2611m

Notes:
Contact ATC to activate RL, REIL, ALS & PAPI.
ILS is available for RWY 09 on frequency 111.10